

## HANGING INSTRUCTIONS [G]

### RECEPTION OF THE MATERIAL

Be sure all material has the same run lot number before installation. Final inspection should be made as to correct pattern, color and any defects in craftsmanship. No claims will be accepted beyond the installation of 3 strips. Absolutely no labour claims will be considered. Application of material is interpreted as acceptance of material and conditions of installation.

This is a natural product, differences of color and aspect between batches are unavoidable. We cannot guarantee a perfect color match between the sample in the pattern book and the delivered goods.

### WALLCOVERING - INSTALLATION

#### 1. WALL PREPARATION

Ensure surfaces are clean, smooth, dry, firm and uniformly colored. Do not hang over glossy or nonporous places, stains. Painted walls should be washed down with Tri Sodium Phosphate to remove grease or soil. Glossy paint should be dulled with sandpaper. Never hang over new plaster or unprimed wall areas. For wallboard, ply or drywall, fill all cracks and prepare the surface with an acrylic basecoat.

#### 2. PREPARATION OF STRIPS

- If your order contains several numbered rolls of one single item/reference, please first install the roll with the highest number, and then continue to install the other rolls in sequence, in descending order.
- Measure and cut 3 strip lengths. Add 2" to 4" (5 to 10 cm) to top and bottom of each strip.
- For printed patterns, plan your match from the roll before cutting.
- Mark each strip coming from the roll on the back and hang in the same sequence.
- Reverse alternate lengths when instructed to do so by label on the roll.

#### 3. INSTALLATION

Apply a ready mixed PVA or EVA clear adhesive to the wall. Follow the instructions of the adhesive manufacturer. Do not use too much adhesive (about 7 ozs/sqyd - 200 gr/m<sup>2</sup>). Respect the open time recommended by the adhesive manufacturer to penetrate into the wall or to evaporate.

#### **ATTENTION !**

- *Make sure the adhesive is spread out evenly over the whole surface to ensure good adhesion to the wall. This will avoid open seams.*
- *Do not use too much adhesive to avoid seam tearing stains on the wallcovering.*
- *Never allow the adhesive to get on front of the material.*



#### **IMPORTANT**

- Attention! Delicate wallcovering. Never allow glue nor water to get on front of the wallcovering!
- Important! Under normal conditions, this reference can be installed by applying the glue directly to the wall, and it is unnecessary to moisten the back of the wallcovering (see also hanging instructions enclosed). However, if this reference has been kept in storage for a long time, and/or if the installation takes place under very warm weather circumstances, it is advisable to first humidify the back of the wallcovering, in order to make the installation easier.